



JCD392 Steam Deck charging problem update Fw (total four steps)


1. Insert the product into the TYPE-C port of the computer
- 2 . 2. Double-click "**usb_bb_dialog**" to open the burning window on the right.




- 3 . Press "**Connect**" and **check the Status window to recognize the chip information before programming.**



4. Click " " in the CUSTOMOCM Update window to select **Fullink_1156_7518_2lane_dongle_cust_15W_2022_0906.hex** update file.




5 . Follow the steps below to start the first firmware update process until the end





6 . After the previous step is updated, continue to the next update step, click in the **ANX7518/7517 FLASH**


OCM Update window to select the  specified update file "**pl_ocm_ba_1.5.16.hex**"




7 . Follow the steps below to start the second firmware update process until the end





8 . Click in the **Update Secure OCM** window to select  the specified update file.



9 . Follow the steps below to start the third firmware update process until the end



10 . Click in the **Update Secure OCM** window to select  the specified update file.



11 . Follow the steps below to start the fourth firmware update process until the end

PHOENIX-LITE EV USB updater V0.6

Platform: Phoenix_Lite

Status
USB connect success
PHOENIX-LITE EV board (CUSTOM), FW version: V0.0
ANX7518/7517 FLASH type, FW version: V1.5.12
Burst: 256 bytes
FW version: N/A
Connect

CUSTOM OCM Update
File Name: C:\Users\FULLINK\Desktop\软件\1156\ANX7518\Fullink_XEDID_CHG D
Size: 0x1000 CheckSum: 0xFAAC Version: Unknow
☒ Write DP ☐ Verify DP

ANX7518/7517 FLASH OCM Update
File Name:
Size:
CheckSum:
Version:
☐ Write PD ☐ Verify PD

Update Secure OCM
File Name: C:\Users\FULLINK\Desktop\软件\1156\ANX7518\hdcp_tx_v1102.hex
Size: 0x3000 CheckSum: 0x2F8F Version: V1102 Start
☒ Write ☐ Verify

Switch to MCU ISP OK

WriteSecreOCM status: 35% Exit

Press Start to start burning

12 . After the previous step is updated, continue to the next update step, click in the **ANX7518/7517 FLASH OCM Update** window to select the specified update file "**pl_ocm_ba_1.5.16.hex**"

PHOENIX-LITE EV USB updater V0.6

Platform: Phoenix_Lite

Status
USB connect success
PHOENIX-LITE EV board (CUSTOM), FW version: V0.0
ANX7518/7517 FLASH type, FW version: v1.5.16 FW version: N/A
Burst: 256 bytes

Connect

CUSTOM OCM Update
File Name: C:\Users\FULLINK\Desktop\软件\1156\ANX7518\Fullink_XEDID_CHG.D ...
Size: 0x1000 CheckSum: 0xFAAC Version: Unknown Start
☒ Write DP ☐ Verify DP

ANX7518/7517 FLASH OCM Update
File Name: ...
Size: CheckSum: Version: Start
☐ Write PD ☐ Verify PD

Update Secure OCM
File Name: C:\Users\FULLINK\Desktop\软件\1156\ANX7518\hdcp_tx_v1102.hex ...
Size: 0x3000 CheckSum: 0x2F8F Version: V1102 Start
☒ Write ☐ Verify

Switch to MCU ISP OK

WriteSecreOCM status: 100%, Update Finish! Exit